



NUTRI BLENDER 400W

Instruction Manual



MODEL: EK-3350B

Balzano products are intended for household use only

Balzano has policy of continuous improvement in product quality and design. The company, therefore reserves the right to change the specification of its model at any time.

Congratulations on purchasing the Nutri Blender 400W!. This user manual is designed to provide you with all the necessary information to set up and utilize your new appliance efficiently. The Nutri Blender is not only a powerful blending tool but also a versatile kitchen companion that opens up a world of culinary possibilities. With its 400 Watt motor and multiple accessories, the Nutri Blender enables you to effortlessly create a wide range of dishes, from smoothies and shakes to soups, sauces, and even homemade nut butters. Whether you're looking to whip up nutritious breakfast smoothies, creamy soups for lunch, or flavorful sauces for dinner, the Nutri Blender has you covered.

Enjoy the journey of creating delicious and nutritious dishes for yourself and your loved ones!

Package Contents

1. Nutri Blender 400W Base Unit
2. 500 ml - 2 Jars
3. 250 ml - 1 Jar
4. 3 Lids
5. 1 Blending Blade
6. 1 Grinding Blade
7. 1 User Manual

Jar Capacities & Uses

First Jar: Suitable for blending up to 500 ml of liquid ingredients.

Second Jar: Can be used as a sipper.

Third Jar: Ideal for grinding up to 250 ml of dry ingredients.

Before First Use

Carefully unpack the blender and remove all packaging materials. Handle the blending blade and the grinding blade attachments by their collars only.

Warning: Do not touch the blades as they are extremely sharp. Use extreme care when handling.

Wash all lids, blades and jars with water and soap. Rinse and dry thoroughly

Assembly

Place the Nutri Blender 400W base unit on a clean, flat surface. Select the blade and the jar you wish to use. Ensure that the area where the appliance is placed is clean and dry.

Usage

Add the desired ingredients into the jar, ensuring not to exceed the recommended capacity.

Close with the appropriate blade unit.

Attach the jar onto the base unit by twisting it clockwise until it is locked in place.

Plug in the Nutri Blender 400W and switch it on.

After use, switch off the Nutri Blender 400W, unplug it from the power source.

Carefully remove the jar from the base unit and empty the contents of the jar.

Cleaning and Maintenance

Ensure that the Nutri Blender 400W is unplugged before cleaning.

Wash both components i.e the jar and the blade unit carefully with water and soap.

Rinse thoroughly and wipe the jar and blade unit carefully.

Wipe the base unit with a damp cloth to remove any spills or residue.

Store the Nutri Blender 400W and accessories in a cool and dry place.

Safety Precautions

Always ensure that the Nutri Blender 400W is unplugged before assembling, disassembling, or cleaning.

Do not operate the appliance without securely attaching the jar.

Avoid overfilling the jars beyond the recommended capacities to prevent spills and damage to the appliance.

Not to be operated by children below 15 years of age